

BaByliss®
ST251U Denim
Luxe Styler



BaByliss ST251U Denim Luxe Styler Instruction Manual

[Home](#) » [BaByliss](#) » BaByliss ST251U Denim Luxe Styler Instruction Manual 

Contents

- 1 BaByliss ST251U Denim Luxe Styler
- 2 Product Specifications
- 3 Product Usage Instructions
- 4 IMPORTANT SAFETY
- 5 INSTRUCTIONS FOR USE
- 6 Heat Settings
- 7 CARE & MAINTENANCE
- 8 UK GUARANTEE
- 9 FAQ
- 10 Documents / Resources
 - 10.1 References

BaByliss®

BaByliss ST251U Denim Luxe Styler



Product Specifications

- **Product Name:** DENIM LUXE STYLER ST251U
- **Heat Settings:** Adjustable for different hair types
- **Auto Shut Off:** Yes, after 60 minutes of continuous use
- **Heat Protection Mat:** Included
- **Guarantee:** 3 years for consumer use within the United Kingdom

Product Usage Instructions

Heat Settings

If you have delicate, fine, bleached, or colored hair, use the lower heat settings. For thicker hair, use the higher heat settings. It is recommended to perform a test on initial use to determine the correct temperature for your hair type. Start at the lowest setting and adjust as needed.

Auto Shut Off

The appliance features an automatic shut-off function for safety. If it has been on continuously for more than 60 minutes, it will turn off. To resume use after this, press and hold the power button for 1-2 seconds.

Heat Protection Mat

Always use the provided heat protection mat during and after styling. Avoid placing the appliance on heat-sensitive surfaces even with the mat. After use, turn off and unplug the device. Keep it away from children as it remains hot for some time.

SAFETY CAUTIONS

Original instructions. Read these safety precautions carefully before using the unit! This appliance should only be used as described within this instruction booklet. Please retain it for future reference.

WARNING! BURN HAZARD: THIS APPLIANCE GETS HOT!

- ALWAYS keep out of reach of children (during and after use and whilst cooling).
- Always take extra care if used on children or near children.
- Do not use on very young children.

IMPORTANT SAFETY

- **UK Only:** This appliance must not be used in the bathroom.
- **Outside the UK:** If using the appliance in a bathroom, unplug it after use as the proximity of water can be dangerous even if the appliance is switched off. For additional protection, the installation of a residual current device (RCD) with a rated residual operating current not exceeding 30mA is advisable in the electrical circuit supplying the bathroom. Ask your installer for advice.
- **WARNING!** Do not use this appliance near bathtubs, showers, basins, or other vessels containing water.
- Do not immerse the appliance in water or other liquids.
- Always inspect the appliance before use for noticeable signs of damage. Do not use if damaged, or if the appliance has been dropped. In the event of damage, discontinue use immediately. Contact the Conair Customer Care Line (refer to the 'UK After Sales Service' section for further information).
- Do not use the appliance if the lead is damaged. In the event of damage, discontinue use immediately. If the lead is damaged it must be replaced by the manufacturer. Return the appliance to the Customer Care Centre (refer to the 'UK After Sales Service' section for further information). No repair must be attempted by the

consumer.

- Do not leave the appliance unattended when switched on or plugged in.
- During use, do not place the appliance on any heat-sensitive surface, even when using the heat mat provided.
- **WARNING!** Only hold the handle during use. Do not touch the hot surfaces of the appliance when in use as these can be extremely hot.
- Take care to avoid the hot surface of the appliance coming into direct contact with the skin, in particular the eyes, ears, face, and neck.
- In the event of the appliance being left switched on, it will automatically shut off after 60 minutes. If you wish to continue using the appliance after this time, simply press and hold the button marked ' **POWER BUTTON**' for 1-2 seconds to turn the power on.
- This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory, or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning the use of the appliance in a safe way and understand, the hazards involved. Children shall not play with the appliance. Cleaning and maintenance shall not be done by children without supervision.
- Allow the appliance to cool before storing it away.
- After use, do not coil the lead around the appliance as this may cause damage. Instead, coil loosely by the side of the appliance.
- Do not use any accessories other than those recommended by BaByliss.
- Always unplug the appliance when not in use or before cleaning.
- This product complies fully with all appropriate EU and UK Legislation and the Standards relevant to this type and class of appliance. We are an ISO9001:2015 certified company that continually evaluates our Quality Management System performance. If you have any queries regarding product safety and compliance, please contact the Conair Customer Care Line. (See the 'UK After Sales Service' section for further information).

INSTRUCTIONS FOR USE

- Ensure hair is dry and combed through to remove any tangles. Divide the hair into sections ready for styling.
- Press and hold the ' ' button for 1-2 seconds to turn the appliance on. The indicator light will start flashing and the appliance will automatically start heating up.
- To select a heat setting suitable for your hair type, press the 'POWER BUTT ' button until the desired heat setting is selected. The indicator light will flash until the selected temperature has been reached. Once the temperature has been reached, the indicator light will remain solid in color.
- Place a section of hair between the straightening plates, close to the roots.
- Hold the hair firmly between the straightening plates and slide down the length of the hair, from root to tip in one smooth movement.
- Repeat for each section of hair.
- Allow the hair to cool before combing through.
- After use, press and hold the ' ' button for 1-2 seconds to switch off and unplug the appliance.
- Allow the appliance to cool before storing it away.

Heat Settings

If you have delicate, fine, bleached, or colored hair, use the lower heat settings. For thicker hair, use the higher heat settings. It is suggested to always complete a test on initial use to ensure the correct temperature is used on the hair type. Start on the lowest setting and increase the temperature until the desired result is achieved. There

are 3 temperature settings to select from; 180°C (Green), 200°C (Yellow), and 235°C (Red).

- **Auto Shut Off**

This appliance has an automatic shut-off feature for added safety. If the appliance is switched on for more than 60 minutes continuously, it will automatically switch off. If you wish to continue using the appliance after this time, simply press and hold the ' ' button for 1-2 seconds to turn the power on again.

- **Heat Protection Mat**

This appliance comes with a heat protection mat for use during and after styling. During use do not place the appliance on any heat-sensitive surface, even when using the heat protection mat provided. After use, switch off and unplug the appliance. Continue to keep the appliance out of the reach of children as it will remain hot for several minutes.

CARE & MAINTENANCE

To help keep your appliance in the best possible condition, follow the steps below:

- Do not wrap the lead around the appliance, instead coil the lead loosely by the side of the appliance.
- Do not use the appliance at a stretch from the powerpoint.
- Always unplug after use.

For more information on this appliance visit www.babyliss.co.uk

UK GUARANTEE

- This BaByliss appliance is guaranteed for consumer use for 3 years and is only valid within the United Kingdom.
- This guarantee covers consumer use only i.e. defects occurring under normal use within the home from the date of purchase or date of delivery, whichever is later.
- If the product develops a fault due to defects in materials or manufacture within 12 months from the date of purchase, to avoid delays and unnecessary inconvenience, where possible please return the product to the point of purchase for an exchange.

If the product develops a fault due to defects in materials or manufacture after 12 months from the date of purchase, and within the guarantee period, Conair UK After Sales Service will repair or replace the product.
Exclusions

This guarantee will no longer be valid meaning that The Conair Group Ltd will not be liable to repair or replace your product where:

1. The appliance has been used on a voltage supply other than that which is marked on the product, or advised within this instruction booklet
2. The appliance has been purchased from an unauthorized stockist*
3. The appliance is used for professional / non-domestic usage
4. Repairs or alterations have been attempted by unauthorized persons
5. The failure of the appliance is a direct result of misuse

6. The failure is a result of not following the instructions for use

This guarantee does not cover any cosmetic damage due to misuse of the product nor any damage to persons or property that occurs because of product misuse. unauthorized stockists include, but are not limited to online auction sites, private sellers and those selling second-hand goods, refurbished products, etc. Please contact the Conair Customer Care Line on 03705 133 191 (09:00 to 17:00 Monday to Friday) or e-mail ukinfo@conair.com for further information on authorized stockists. It is important to retain your proof of purchase. We recommend attaching your receipt to this page. Even where a refund may be applicable, no refund will be provided without a valid receipt or proof of purchase, we will only be able to offer a repair or replacement service. Please note this does not apply if the product was purchased directly from The Conair Group Ltd. Guarantees on replacement products run from the original purchase date or date of delivery, whichever is later, and not from the date of replacement. This guarantee is an additional benefit and does not affect your statutory rights as a consumer.

If you have any queries regarding this guarantee please contact the Conair Customer Care Line on 03705 133 191 (09:00 to 17:00 Monday to Friday) or e-mail ukinfo@conair.com

UK AFTER-SALES SERVICE

For further advice on using the appliance or should you need to return your product, please contact the Conair Customer Care Line on 03705 133 191 (09:00 to 17:00 Monday to Friday) or e-mail your enquiry to ukinfo@conair.com

Return address:

Customer Care Centre Conair Logistics Unit 4, Revolution Park Buckshaw Avenue Buckshaw Village Chorley PR7 7DW

Please enclose your return number, name and address details, together with a copy of proof of purchase and details of the fault. Please note this Instruction Booklet is not the guaranteed.

SAFE DISPOSAL: The symbol on the product or on its packaging indicates that this product may not be treated as household waste. Instead, it should be handed to an appropriate collection point for the recycling of Electrical and Electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. For more detailed information about the recycling of this product, please contact your local council office or your household waste disposal service.

FAQ

What is the warranty period for this product?

The product is guaranteed for consumer use within the United Kingdom for 3 years from the date of purchase or delivery.

What should I do if the product develops a fault?

If a fault occurs due to defects within 12 months of purchase, return it to the point of purchase for an exchange. After 12 months, Conair UK After Sales Service will repair or replace the product within the guarantee period.

What are the exclusions to the warranty?

The warranty will not cover issues arising from misuse, use on an incorrect voltage supply, purchase from unauthorized sellers, professional/non-domestic use, unauthorized repairs, or failure to follow instructions.

Documents / Resources



This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.